



FLOATING LAKE  
FOUNTAINS

Lake Fountain Nozzle Change  
5-Step Quick Install Guide

**ARBRUX**  
MANUFACTURING

# Step 1: Remove Screws

- Remove four nozzle retaining screws.



# Step 2: Check for Debris

- Remove nozzle and flow straightener and check for debris.



# Step 3: Install O Ring

- Ensure O ring is installed in groove shown on new nozzle.
- *Applying a light film of vegetable oil to O ring will make installation easier.*



# Step 4: Install Flow Straightener

- Ensure flow straightener is installed as shown.



# Step 5: Install Screws

- Install nozzle and screws.



FLOATING LAKE  
**FOUNTAINS**



**ARBRUX**  
MANUFACTURING

Enjoy your new Spray Pattern!